

Linux Support

Ubuntu 16.04, 18.04 and 19.04 Support

You can install the ProfiShark driver for the latest generic kernels provided in Ubuntu 16.04.x, 18.04.x and 19.04.x, as well as the other ProfiShark software for Ubuntu 16.04.x, 18.04.x and 19.04.x, using our repository located at <https://ubuntu.profitap.com/> with the following commands:

```
wget https://ubuntu.profitap.com/public.key
sudo apt-key add public.key
sudo add-apt-repository https://ubuntu.profitap.com/
sudo apt-get update
```

After these commands, you should be able to see all the available drivers, using:

```
apt-cache search profishark-linux
```

and install the one you need with:

```
sudo apt-get install profishark-linux-driver-X.YY.0-ZZ
```